

ERRORS:

- A01: Keyboard temperature board faulty;
- A02: High temperature alarm on technical compartment;
- A03: Safety probe on TRIAC board faulty;
- A04: High temperature alarm on TRIAC board;